

**Table 2: Commissioning Menu - Flow (Continued)**

Menu Option	Description	Range
<b>Unoccupied Heating Min Flow</b>	Sets the minimum supply air flow of the VAV box when in unoccupied heating and heating mode.	Adjustable: 0 to 1,000 cfm
<b>Warmup Min Flow</b>	Displays the minimum flow to the VAV box during morning warmup.	Adjustable: 0 to 1,000 cfm
<b>Staged Reheat Min Flow</b>	Sets the minimum heating flow for staged reheat control.	Adjustable: 0 to 1,000 cfm

**Manufacturer Damper Data**

**Table 3: Manufacturer Damper Data**

Manufacturer	Default Direction to Close
<b>ETI</b>	Clockwise
<b>Kruger</b>	Counterclockwise
<b>Titus</b>	Counterclockwise
<b>Tuttle and Bailey</b>	Counterclockwise

**Additional Information**

Refer to the *Verasys System Operation Overview Technical Bulletin (LIT-12012370)* for more information on the various sequences performed by adjusting the control parameters.

For additional information about Verasys, use the QR code or visit [www.verasyscontrols.com](http://www.verasyscontrols.com).



**European Single Point of Contact:**

JOHNSON CONTROLS  
WESTENDHOF 3  
45143 ESSEN  
GERMANY

**NA/SA Single Point of Contact:**

JOHNSON CONTROLS  
507 E MICHIGAN ST  
MILWAUKEE WI 53202  
USA

**APAC Single Point of Contact:**

JOHNSON CONTROLS  
C/O CONTROLS PRODUCT MANAGEMENT  
NO. 22 BLOCK D NEW DISTRICT  
WUXI JIANGSU PROVINCE 214142  
CHINA



24-10143-1418, Rev. -

(barcode for factory use only)




**ZEC410 VAV  
Controller  
QUICK START GUIDE**



# GETTING STARTED

This guide provides you with the minimum configuration requirements that you need to quickly bring the system communication and controls online with the Smart Building Hub (SBH).

## Equipment Setup Menu




**Table 1: Equipment Setup Menu**

Menu Option	Description	Range
<b>Damper Polarity</b>	Sets the direction to close the zone damper.	Adjustable: clockwise/counterclockwise
<b>Box Heating Installed</b>	When set to True, the controller uses the outputs to control the heat in the VAV box.	Adjustable: True, False <b>Note:</b> Model ZEC410-1 controls staged heat, model ZEC410-2 controls floating or incremental heat, and model ZEC410-3 controls proportional heat.

**Table 1: Equipment Setup Menu (Continued)**

Menu Option	Description	Range
<b>Supplemental Heating Installed</b>	When set to True, the controller uses the outputs to control the supplemental heat in the space.	Adjustable: True, False <b>Note:</b> Model ZEC410-1 controls staged heat, model ZEC410-2 controls floating or incremental heat, and model ZEC410-3 controls proportional heat.

## Commissioning Menu - Flow



**Table 2: Commissioning Menu - Flow**

Menu Option	Description	Range
<b>Cooling Maximum Flow</b>	Sets the maximum supply air flow of the VAV box when cooling.	Adjustable: 0 to 10,000 cfm
<b>Occupied Cooling Min Flow</b>	Sets the minimum supply air flow of the VAV box when cooling.	Adjustable: 0 to 10,000 cfm
<b>Occupied Heating Min Flow</b>	Sets the minimum supply air flow of the VAV box when heating.	Adjustable: 0 to 10,000 cfm <b>Note:</b> When the zone is heating, the supply airflow is constant and there is no maximum heating airflow.
<b>Supply Area</b>	The supply inlet area used to calculate the supply flow.	Adjustable: 0 to 8.0 sq. ft.
<b>Pickup Gain</b>	Shows the K factor for the box. This parameter calibrates the flow.	Adjustable: True/False
<b>Unoccupied Cooling Min Flow</b>	Sets the minimum supply air flow of the VAV box when in unoccupied cooling and unoccupied mode.	Adjustable: 0 to 1,000 cfm